




PORSCHE 911 TYPE with HEAD & BRAKELIGHTS

See overleaf for list of spare parts





PORSCHE 911 TYPE with HEAD & BRAKELIGHTS

List of Parts	
<i>Ref. No.</i>	<i>Item</i>
W.5126	PCB with Brakelights
W.5148	Magnet Assembly
L.5543	Wheel Hub (<i>State colour required</i>)
L.6081	Light Unit.....
L.6528	Underpan
M.2055	Motor with Harness
M.2198	Bulb.....
S.1152	Screw
S.8860	Eyelet.....
S.9536	Contrate Gear.....
S.9747	Tyre.....
01796	Motor Pinion.....
02545	Front Axle Spacer
05192	Rear Axle Bearing.....
05318	Pick-up Braid (<i>Pack of 6</i>)
06008	Guide Blade.....
06074	Axle.....






See overleaf for list of parts

PORSCHE 911 TYPE with

HEAD & BRAKELIGHTS





PORSCHE 911 TYPE

List of Parts	
<i>Ref. No.</i>	<i>Item</i>
W.1439	Guide Blade Assembly
W.2072	Front Axle Assembly
W.2073	Rear Axle Assembly
W.5126	PCB with Brakelights
L.3328	Keeper Plate.....
L.5543	Hub
L.6081	Light Lens
L.6528	Underpan.....
M.2055	Motor with Pinion and Harness.....
M.2198	Bulb.....
M.2596	Magnet
M.2985	Eyelet
S.1250	Screw.....
S.2498	Axle.....
S.9536	Contrate Gear
S.9747	Tyre.....
01796	Motor Pinion.....
02545	Front Axle Spacer
05192	Rear Axle Bearing